


WX240



WX240

	Part No	Description	Qty
1	60056856	Fore Cover	1
2	60056857	Lamp cap	2
3	60056858	Output shaft	1
4	60056859	Spring washer	1
6	60056861	Shaft cover	1
7	60056862	Gear case	1
8	60056863	Circlip	1
9	60056864	Fixing Ring	1
10	60056865	Self-locking core	1
11	60056866	Self-locking pin	6
12	60056867	Self-locking block	1
13	60056868	Planet Gear	6
14	60056869	Center toothed disc	1
15	60056870	Shim Ring	1
16	60056871	Screw	2
17	60056872	Fixed Plate	1
18	60056873	Motor gear	1
19	60056874	Motor	1
20	60056875	Left/Right Fixing frame	1
21	60056876	Protection board	1

WX240

	Part No	Description	Qty
22	60056877	Insulating paper	1
23	60056878	Button	1
24	60056879	Self tapping screw	2
25	60056880	Charging plug	1
26	60056881	Rear Cover	1
27	60056882	Housing	1
28	60056883	Terminal	2
29	60056884	Cell	1
33	60056885	Button	1
34	60056900	Torque label	1
40	60056892	USB charging cable(Type-C)	1
101	60056886	Motor Set	1
102	60056887	Fore Cover Set	1
103	60056888	Battery and circuit board set	1
104	60056889	Rear cover set	1
105	60056890	Gearbox set	1
106	60056891	Motor circuit board set	1
F3	60066229	Bubble Dress	1
F4	60066258	Extension pole	1