


WX711




WX711

	Part No	Description	Qty
1	60039815	Nut M6	1
2	60039816	Small gear	1
3	60039817	Ball Bearing 608	1
4	60039818	Baffle	1
5	60039868	Rotor	1
6	60039820	Ball Bearing 607	1
7	60039821	Bearing Sleeve	1
8	60039869	Stator	1
9	60039823	Housing Decorative Ring II	1
10	60039824	Self Tapping Screw	4
11	60039825	Spindle Lock Cap	1
12	60039826	Compression Spring	1
13	60039827	Spindle Lock Pin	4
14	60039828	Fore Housing	1
15	60039829	Oil Seal Bearing	1
16	60039830	Big gear	1
17	60039831	Retaining Ring	1
18	60039832	Ball Bearing 6201	1
19	60039833	Dust Roof Plate	1
20	60039870	Spindle	1

WX711

	Part No	Description	Qty
21	60039835	Fore Cover	1
22	60039871	Guard	1
23	60039837	Guard Handle	1
24	60039838	Spring pin	1
25	60039872	Inner Flange	1
26	60039873	Outer Flange	1
27	60039841	Bearing Sleeve	1
28	60039874	Wind Baffle Ring	1
29	60039843	Housing	1
30	60039844	Self Tapping Screw	2
31	60039875	Brush Holder	2
32	60039846	Spiral spring	2
33	60039876	Carbon Brush(pair)	1
34	60039848	Self Tapping Screw	2
35	60039849	Cord Clamp	1
36	60039850	Capacitor	1
37	60044746	Switch	1
38	60039852	Switch lever	1
39	60039853	Trigger	1
40	60039854	Housing Cover	1

WX711

	Part No	Description	Qty
41	60039855	Housing Decorative Ring I	1
42	60039856	Cable Protector	1
43	60039877	Power Cord	1
44	60039879	Spanner	1
45	60039859	Side Handle	1
46	60039860	Screw	4
47	60039861	Self Tapping Screw	1
48	60039884	Washer	1
101	60039880	Rotor Set	1
102	60039863	Fore Housing Assembly	1
103	60039881	Fore Cover Assembly	1
104	60039882	Guard Set	1
105	60039883	Brush Holder Assembly	2
106	60039867	Housing Cover Set	1