


WBBC7623LC Spare parts list Service code: WBBC7623LC2410

Note vulnerable properties: Refers to the degree of wear and tear in the day-to-day operation of the correct use of this part which according to guide customers reasonable reserves. A for wear and tear very easily, B for wear and tear is easy while C for wear and tear is not easy, and we suggest having basic inventory. We suggest that you still need to have basic inventory of C


Subassembly code	Name_English	Machine breakdown	parts list
1	Engine part		
2	Blade system		
3	Main base plate		
4	Rear axle		
5	Handle and controls		
6	Wiring loom		

Model: WBBC7623LC
Service code: WBBC7623LC2406
Engine part




1	Part1 Engine Spare parts list		
Order	Part number	Name_English	Quantity
1	LC2P80F/L1256	Engine	1
2	5320115010	Bolt - 3/8-16*25.4 12.9	4
3	13910001	Belt	1
4	13910014	Key	1
5	1391000202	Engine pulley	1
6	13910017	Clutch	1
7	13810010	Spring washer - 7/16	1
8	DL20204C2	Bolt - 7/16-20*2-1/2 10.9	1
9	1391000540	Left fixed plate	1
10	1391000740	Right fixed plate	1
11	1391000940	Engine protective net	1
12	0102006012	Bolt - M6*12	10
13	1391001040	Right support plate	1
14	1391001240	Left support plate	1
15	0102006016	Bolt - M6*16	2

Model: WBBC7623LC
Service code: WBBC7623LC2410
Blade system




2	Part2 Blade system Spare parts list		
Order	Part number	Name_English	Quantity
1	50670001	Lock nut - M16*1.5	1
2	1392000202	Blade washer	1
3	1392000132	Blade	1
4	1392000322	Protective sleeve	1
5	1392000404	Blade shaft	1
6	6205-2ZS	Bearing	3
7	1392000502	Bearing washer	1
8	1392000602	Bearing spacer sleeve	1
9	1392000722	Bearing seat	1
10	1392000802	Blade pulley	1
11	50570002	Key	1
12	0301020000	Flat washer - ϕ 20	1
13	13920052	Nut - M20*1.5-L	1
14	13920053	Thin nut - M20*1.5-L	1
15	13920011	Belt	1
16	0102010020	Bolt - M10*20	20
17	0107012050	Bolt - M12*50	2
18	0206012000	Nut - M12	2
19	13920012	Bearing	2
20	1392001322	Bracket	1
21	0102010060	Bolt - M10*60	1
22	0901040000	Circlip - ϕ 40	1
23	6203-2RS	Bearing	1
24	1392001802	Tensioner pulley	1
25	1392002102	Tensioner sleeve	1
26	1392002202	Tensioner arm	1
27	1392002502	Spacer sleeve	1
28	50680001	Nut - M10	6
29	0101010090	Bolt - M10*90	1
30	0302010000	Big flat washer - ϕ 10	1
31	4SC1908010	Cooper bush	1
32	13920026	Tensioning spring	1
33	2501006000A	Oil cup - M6	1
34	1392002704	Spacer sleeve for tensioning arm	1
35	1392002844	Blade cover	1
36	0302008000	Big flat washer	4
37	0102008020	Bolt - M8*20	10
38	0102010040	Bolt - M10*40	4
39	1392002922	Reinforcement plate	1
40	1392003344	Blade disc	1
41	1392003740	Height adjusting	1
42	0301008000	Flat washer - ϕ 8	12
43	0202008000	Nut - M8	12
44	1392004040	Left height adjusting rod	1
45	13920043	Rubber skin	1
46	1392004422	Pressure plate	1
47	1392004540	Bumper	1
48	0102008040	Bolt - M8*40	6
49	13920046	Plug - Φ 20	2
50	1392004722	Support bracket	1
51	0301006000	Flat washer - ϕ 6	2
52	0202006000	Nut - M6	2
53	1392004822	Shaft for front baffle	1
54	1392004922	Front baffle	1
55	13920054	Blade Kit	1
56	13920056	Dust cover for bearing seat	1

Model: WBBC7623LC
Service code: WBBC7623LC2410
Main base plate




3 Part3 Main base plate Spare parts list			
Order	Part number	Name_English	Quantity
1	0102008030	Bolt - M8*30	4
2	0302008000	Big washer - φ8	4
3	16620-Z120210-H7A0	Tank	1
4	0102008020	Bolt - M8*20	10
5	1393000222	Tank bracket	1
6	0202006000	Lock nut - M6	3
7	0301006000	Flat washer - φ	3
8	WB9670004	Relay	1
9	0102006016	Bolt - M6*16	3
10	1393000622	Rear deflector	1
11	0102010020	Bolt - M10*20	2
12	1393000701	Left support plate	1
13	4820113010	Bolt - 5/16-18×16	2
14	13930034	Rubber ring - Φ25	1
15	1393000801	Right support plate	1
16	1393004344	Main seat plate	1
17	13930018	Positioning sleeve	1
18	13930019	Pin - M8*60	1
19	1393002002	Lock sleeve	1
20	1393002102	Limited rod	1
21	1393002302	Belt limiter	2
22	0204010000	Metal lock nut - M10	1
23	0302010000	Big washer - φ10	2
24	0202010000	Lock nut - M10	2
25	0102010060	Bolt - M10*60	1
26	0901035000	Circlip - 35	1
27	1393003602	Drive tensioner	1
28	6202-2RS	Bearing	1
29	1393002702	Tensioning cushion sleeve	1
30	1393003702	Tensioning arm	1
31	1392002502	Spacer sleeve	1
32	13930032	Tensioning spring	1
33	GM56A060000080	Soliding bearing	2
34	0303008000	Big washer - φ8	1
35	0401008000	Spring washer - φ8	1
36	0101008020	Bolt - M8*20	1
37	1393003302	Spacer	3
38	Z122420014	Relay	1

Model: WBBC7623LC
Service code: WBBC7623LC2410
Rear axle



4 Part4 Rear axle Spare parts list			
Order	Part number	Name_English	Quantity
1	13940025	Wheel nut - M12*1.25	10
2	13940026	Wheel	2
4	1001038000	Circlip - Φ38	2
5	0702008035	Pin - Φ8*35	2
6	0111012040B	Wheel bolt - M12*1.25*40	10
7	1394000302	Brake hub flange	2
8	13940004	Brake hub assembly	2
8,1	13940030	Brake block	2
9	6007-2RS	Bearing	2
10	1394000502	Left connecting plate	1
11	0301008000	Flat washer - Φ8	20
12	0401008000	Circlip - Φ8	12
13	0103008016	Screw - M8*16	12
14	0202008000	Nut - M8	8
15	13940009	Transmission	1
16	1394001002	Right connecting plate	1
17	4510117010	Nylon spacer	4
18	0801008020	Pin - 8*20	2
19	05012P5022	Split pin - 2.5*22	2
20	1394001402	Speed regulating plate	1
21	4SC3609020	Big washer	1
22	0401006000	Spring washer - φ6	1
23	CM030000190	Fixing bolt	1
24	0102010020	Bolt - M10*20	6
25	1394002701	Left support seat	1
26	1394001602	Spacer sleeve	4
27	50020002	Bolt - M8*65	8
28	1394001702	Transmission pulley	1
29	1001016000	Circlip - Φ16	1
30	1394002022	Left grass guard	1
31	0102008020	Bolt - M8*20	4
32	1394002322	Right grass guard	1
33	1394002801	Right support seat	1
34	1394002902	Spacer, Speed adjusting board	1


Model: WBBC7623LC
Service code: WBBC7623LC2410
Handle and controls



5	Part5 Handle and controls Spare parts list		
Order	Part number	Name_English	Quantity
1	0202008000	Nut - M8	14
2	0301008000	Flat washer - ϕ 8	14
3	1395000144	Left handle	1
4	1395000644	Right handle	1
5	1395001144	Left reinforcement rod	1
6	1395001244	Right reinforcement rod	1
7	0102008040	Bolt - M8*40	8
8	0102008045	Bolt - M8*45	4
9	0202006000	Lock nut - M6	11
10	1395001344	Battery bracket	1
11	13950057	Battery pad 2	1
12	DC12036	Battery	1
13	13950058	Battery pad 1	1
14	0128008020	Bolt - M8*20	2
15	1395001622	Battery pressure plate	1
16	13950059	Handle sheath	2
17	1395001702	Left parking lock hook	1
18	13950020	Left parking spring	1
19	1395002122	Brake steering handle	2
20	0801008024	Pin - 8*24	2
21	05012P5022	Splitpin - 2.5*22	2
22	0104006025	Screw - M6*25	2
23	0104006035	Screw - M6*35	2
24	0104006040	Screw - M6*40	5
25	1395002240	Hand guard	2
26	0103006020	Screw - M6*20	2
27	0302006000	Big washer - ϕ 6	2
28	45A0323010	Big handle sheath	2
29	1395002349	Blade disc handle	1
30	13950025	Blade disc cable	1
31	0301006000	Flat washer - ϕ 6	17
32	1301005000	Circlip - ϕ 5	2
33	1395002640	Clutch handle	1
34	0104005025	Screw - M5*25	1
35	0302005000	Big washer - ϕ 5	1
36	0104004012	Bolt - M4*12	1
37	1395002702	Binding post	1
38	1395002802	pressing plate	1
39	1395002902	Start switch pad	1
40	Z61C0300	Control switch	1
41	1395003002	Support sleeve	1
42	1395003101	Support plate	1
43	0102008020	Bolt - M8*20	4
44	0202005000	Lock nut - M5	9
45	0202003000	Lock nut - M3	2
46	Z42ED14000/22	Pressure plate for micro switch	1
47	13950032	Micro switch	1
48	0104003025	Screw - M3*25	2
49	1395003301	Speed adjusting handle	1
50	0301005000	Flat washer - ϕ 5	9
51	13950036	Limit plate	1

5		Part5 Handle and controls Spare parts list	
Order	Part number	Name_English	Quantity
52	1395003701	Cover limit plate	1
53	0104005020	Screw - M5*20	8
54	2101008020	Handle ball	1
55	0202010000	Nylon lock nut - M10	1
56	0302010000	Big washer - φ10	1
57	GT68WA08000/02	Spring	1
58	1395003801	Speed adjusting turntable	1
59	0501002016	Splitpin - 2*16	3
60	1395004001	Support plate	1
61	Z122241001	Throttle assembly	1
62	Z122241001	Throttle assembly	1
63	Z122245011A1	Rubber pad	1
64	13950042	Emergency stop	1
65	Z61E0300	Start switch	1
66	1395004344	Control panel	1
67	13950046	Brake cable	2
68	13950047	Clutch cable	1
69	13950048	Speed regulating cable	2
70	13950049	Throttle cable	2
71	4SC1307010C	Spring 1	1
72	13950050	Right parking torsion spring	1
73	1395005102	Right parking lock hook	1
74	0104006050	Screw - M6*50	1
75	13950054	OPC start spring	1
76	1395005549	OPC limit plate	1
77	Z61C0100	Key	1

Model: WBBC7623LC
Service code: WBBC7623LC2410
Wiring loom



6 Part6 Wiring loom Spare parts list			
Order	Part number	Name_English	Quantity
1	BXS020A	Fuse 20A	1
2	13960002	Main wire	1
3	Z61E0300	Ignition switch	1
4	Z61C0100	Key	1
5	13950042	Emergency stop button	1
6	13950032	Neutral safety switch	1
7	Z61C0300	Blade hold-to-run switch	1
8	13960009	Battery black sheath	1
9	13960010	Battery red sheath	1
10	DC12036	Battery	1
11	WB9650008	Protective sheath 12*22	3
12	13960006	Electric clutch wire	1
13	Z122420014	Clutch relay	1
14	13960004	Electric clutch wire	1
15	13960005	Start motor wire	1
16	WB9650012	Black protective sheath - 14*8	1
17	WB9670004	Start relay	1
18	WB9650011	Red protective sheath - 14*8	1
19	13960003	Positive wire	1